Bandido creates products that generate harmony and warmth in each space where they are present. We hope you enjoy your new product and exceeds all your expectations.

You can get more information about the maintenance of your product and warranty by scanning the following **QR Code**.



Distrito Bandido

RFC: DBA200515RT3 Callejón del Cristo 2 - 6A Col. San José del Puente C.P. 72150. Puebla, Puebla

+52 (222) 688 8442 www.bandidostudio.com

FASE Floor Lamp Instructions



Bandido

1 x LED module 18 W 127 V ~ 60 Hz 18 W LED 0.141 A Included 18 Wh

Indoor use

Light Source

Indications of use

- Unpack carefully. The materials are brittle and can easily crack
- 2 Connect plug to electrical outlet.
- **3** Use button switch to turn on and off.

Spare parts

- To replace the LED module, contact Bandido directly.
- Driver integrated in the product.