Bandido creates products that generate harmony and warmth in each space where they are present. We hope you enjoy your new product and exceeds all your expectations.

You can get more information about the maintenance of your product and warranty by scanning the following **QR Code**.




Distrito Bandido

RFC: DBA200515RT3 Callejón del Cristo 2 - 6A Col. San José del Puente C.P. 72150. Puebla, Puebla

+52 (222) 688 8442 www.bandidostudio.com

B FASE

Sconce Lamp
Instructions



Bandido

Indications of use

Light Source

Included 15 Wh

Indoor use

1 x LED module 15 W

127 V ~ 60 Hz 15 W LED 0.118 A

- Unpack carefully. The materials are brittle and can easily crack.
- 2 Follow instructions on back of sheet for installation of this product.

Spare parts


- To replace the LED module, contact Bandido directly.
- Driver integrated in the product.

We suggest that any electrical work should be performed by a qualified electrician.


Parts included.




Before drilling, use the **Fixation Template** to mark the screw positions, ensuring they are aligned, level, and horizontal.



2 Placement of hexagonal screws.




Connect the wires + to + and - to - through the connector.




*Leave a 2-3 mm separation from wall.

4 Carefully align the fixture body and position it onto the hexagonal screws.



5 Onyx diffuser placement and Brass / Steel disk.



*Place Driver inside the hole on wall.

*Rubber washer.

TEMPLATE

Sconce Lamps

Assembly Instructions

- 1. Place template on the surface where the sconce lamp will be installed.
- 2. Align and level the template using reference line.
- 3. Mark drilling holes with guide bit.
- 4. Drill using a 3/8" bit.

