


Bandido creates products that generate harmony and warmth in each space where they are present. We hope you enjoy your new product and exceeds all your expectations.

You can get more information about the maintenance of your product and warranty by scanning the following QR Code.



B HUMO 18

Sconce Lamp Instructions



CDMX

Aristóteles 127
Polanco IV Sección Miguel Hidalgo
11550 CDMX, México

+52 555 087 2443

PUEBLA

Callejón del Cristo 2 Int. 6 A
Col. San José del Puente
72150 Puebla, Pue, México

+52 222 688 8442

Light Source

2 x 2.5 W G9 LED COB 250 lm
120 - 127 V ~ 60 Hz 0.020 A
2700K
Included


Indoor Use

bandidostudio.com


Bandido

BULB REPLACEMENT


1



2



3



* Align and screw in slightly,
the diffuser may break.

 Handle with care, fragile materials.

 Use only LED bulbs.

INSTALLATION GUIDE


Sconce Lamp



CAUTION: Turn off the power supply before executing any electrical installation.


We suggest that any electrical work be performed by a qualified specialist.

Included Parts:




1 Placement of wall plugs. Before drilling, mark the location of the screws according to the **installation template**.

* Electrical supply cables.




2 Fixing the steel plate.

* Use the labels as a guide for positioning the diffusers.





3 Connect + to + and - to - using the connector.



4 Secure body to steel plate.

* Remove label once the lamp has been installed.



* Allen screws are pre-installed.



Handle with care, fragile materials.


TEMPLATE

PL11

HUMO Sconce Lamp

Installation guide

1. Place this template on the surface where the luminaire will be installed.
2. Align and level the template using the reference line.
3. Mark the drilling holes.
4. Drill.



Scale 1:1



0.3 in

Bandido