
Bandido creates products that generate harmony and warmth in each space where they are present. We hope you enjoy your new product and exceeds all your expectations.

You can get more information about the maintenance of your product and warranty by scanning the following **QR Code**.



AXIS

Sconce Lamp Instructions



Distrito Bandido

RFC: DBA200515RT3

Callejón del Cristo 2 - 6A Col. San José del Puente C.P. 72150. Puebla, Puebla

+52 (222) 688 8442 www.bandidostudio.com

Bandido


Bulb replacement Tutorial


Light Source


Indoor use


1 x G9 LED 6W max.

120 V ~ 60 Hz 0.020 A Included 5 Wh










We suggest that any electrical work be performed by a specialist.

Piezas incluidas.




Placement of wall plugs. Before drilling, mark the location of the metal bars according to the Fixing Template and ensure that they are correctly aligned.


GENERAL INSTALLATION DIAGRAM




2 Connect the cables +with+&-with-through the thermofit.




3 Insert the lamp into the metal bars.



*Place cables through the hole on wall.






TEMPLATE

AXIS - Sconce Lamps

Installation Guide

- 1. Place template on the surface where the sconce lamp will be installed.
- 2. Align and level the template using reference line.
- 3. Mark drilling holes.
- 4. Drill.



1:1 Scale Bandido